



- 1) Multimeter Setting
- 2) Place Prong in #2 hole
- 3) Once circuit is close the multimeter should beep to verify continuity